



Toshiba NB205 N330PK Webcam Replacement

This extensive guide demonstrates how to remove the webcam from the netbook for replacement or maintenance (6 Steps).

Written By: Mason McCaskill





TOOLS:



- [Spudger](#) (1)
- [64 Bit Driver Kit](#) (1)
- [Phillips #0 Screwdriver](#) (1)
- [Tweezers](#) (1)



PARTS:




- [Webcam for Toshiba NB205](#) (1)

Step 1 — Webcam




- Use a spudger to remove the small rubber screw coverings above each retaining screw.
- Use the bit driver with a Phillips #0 bit to remove the two 5 mm screws securing the screen bezel.

Step 2




- Using a spudger, gently pry the screen bezel to the condition of the photograph.
- *i* For this procedure, it is not necessary to completely removal screen bezel so in order to reduce work, bezel is just partially removed.

Step 3




- Using pliers, gently remove the electrical connection to the webcam by pulling the plug to the right (per orientation of the photo).
- Allow the removed wire to hang in place but make note of alignment with respect to webcam.
- ⓘ This step is performed while holding down the bezel which is only partially detached.

Step 4





- Use the spudger to pry each side of the webcam until it releases from its adhesive back.

Step 5



- Position the new webcam in the old webcam's position. The webcam must be carefully aligned in order to function properly with the bezel in place. Align the hole of the webcam assembly over the cylinder of the webcam stabilizer.
- Reconnect the electrical connection.

Step 6



- Gently press the front bezel back into its original position.
- Using the bit driver and Phillips #0 bit, drive the two bezel retaining screws in to place.
- Cover the screws with the small covers with tweezers.

